




H0086 INSTRUCTION MANUAL
 H0087 DECAL MRX-4X
 H0088 DECAL MRX-4X 3pcs.
 D0104R REAR LOWER SUS. SHAFT
 H0104L FRONT LOWER SUS. SHAFT
 J0105U REAR UPPER SUS. SHAFT
 D0105R KING PIN
 H0107/1 FRONT STABILIZER BAR
 H0135 FRONT UPPER ARM
 H0136-B REAR UPPER ARM
 H0137 FRONT LOWER ARM
 H0138 REAR LOWER ARM
 H0139-B FRONT UPRIGHT
 H0140-B REAR UPRIGHT
 H0141 FRONT ANTI-ROLL BAR HOLDER
 H0142 RADIO PLATE MOUNT
 H0143 MIDDLE SHAFT BRACKET
 H0144 KING PIN BALL CUP
 H0145 ADJUST NUT
 H0146 SUS. ARM SPACER
 H0147 REAR UPPER ARM SET
 H0148-B FRONT BULKHEAD
 H0149-B REAR BULKHEAD
 T0154 ECCENTRIC HUB




H0158 FRONT UPRIGHT
 H0161 FRONT UPPER SUS. SHAFT
 H0163 REAR ANTI-ROLL BAR
 H0164 ROLL BAR
 H0180 REAR UPRIGHT BALL
 H0181 REAR UPRIGHT SPACER
 H0181A 3mm SPACER 0.5mm
 H0181B 3mm SPACER 1.0mm
 H0181C 3mm SPACER 2.0mm
 H0181D 3mm SPACER 3.0mm
 H0185 REAR ADJUSTABLE ANTI-ROLL BAR SET
 H0186 REAR ADJUSTABLE ANTI-ROLL BAR
 H0187 TITANIUM KING PIN BALL (2 pcs.)
 H0187/1 TITANIUM KING PIN BALL (8 pcs.)
 H0188 ECCENTRIC HUB
 H0189 UPRIGHT SPACER
 H0190 BRAKE BRACKET
 H0191 REAR LOWER ARM MOUNT
 H0205 PULLEY HUB
 D0206 INNER DRIVE JOINT
 H0208 FRONT AXLE SHAFT
 J0209 MIDDLE SHAFT
 H0222 REAR AXLE SHAFT




D0240 BELT S 6mm
 H0240 BELT S 8mm
 H0241 BELT L 6mm
 H0245 BELT S 6mm RUBBER
 H0246 BELT S 9mm RUBBER
 H0247 BELT L 6mm RUBBER
 H0252 FRONT ONE WAY DRIVE AXLE
 H0253 FRONT DRIVE SHAFT
 H0255 BRAKE PULLEY ADAPTER
 H0256 2 SPEED SHAFT
 H0257 2 SPEED ADAPTER
 H0268 AXLE WASHER
 H0269 TITANIUM MIDDLE SHAFT
 H0270 FRONT UNIVERSAL JOINT SET
 H0271 FRONT AXLE SHAFT FOR UNIVERSAL
 H0272 FRONT DRIVE SHAFT FOR UNIVERSAL
 H0273 JOINT SHAFT FOR UNIVERSAL
 H0274 ROLLER PIN ϕ 2.5x11.8 (10 pcs.)
 H0275 FRONT WHEEL CHANGE LEVER
 H0277 REAR AXLE SHAFT FOR UNIVERSAL
 H0279 REAR WHEEL CHANGE LEVER



H0280 PULLEY SET
 H0281 1st. GEAR 48T
 H0282 1st. GEAR 49T
 H0283 1st. GEAR 50T
 H0284 2nd. GEAR 45T
 H0285 2nd. GEAR 46T
 H0286 2nd. GEAR 47T
 H0287 SHOE FOR 2 SPEED GEAR BOX
 H0288 HOUSING FOR 1st. GEAR
 H0289 HOUSING FOR 2nd. GEAR
 H0290 REAR SOLID AXLE
 H0291 REAR DRIVE SHAFT
 H0292 BELT TENSIONER PLATE
 H0293 BELT TENSIONER SHAFT
 H0295 SPRING FOR 2 SPEED GEAR BOX
 H0296 REAR UNIVERSAL JOINT SET
 H0297 REAR DRIVE SHAFT FOR UNIVERSAL
 H0354 BRAKE CAM
 H0354 BRAKE PLATE
 H0355 BRAKE PAD
 H0359 TEFLON BRAKE PAD
 H0362 SERVO MOUNT PARTS



H0365 SERVO SAVER SHAFT
 H0366 SERVO SAVER PIPE
 H0367 SERVO SAVER SPRING
 H0368 GROGMET
 H0369 VENTILATED BRAKE DISK
 H0370 RADIO PLATE
 H0371 TH SERVO MOUNT
 H0372 SERVO SAVER ARM
 H0373 RADIO MOUNT PARTS
 H0374 BATTERY HOLDER FRP
 H0375 BATTERY HOLDER CFRP
 H0463 FRONT BUMPER
 H0465 FRONT BODY MOUNT
 H0466-B REAR BODY MOUNT
 H0467 REAR BODY MOUNT CENTERING PLATE
 H0468 REAR BODY MOUNT CENTERING SHAFT
 H0469 REAR BODY MOUNT ARM SHAFT
 H0470 REAR BODY MOUNT ARM STOPPER
 H0471 REAR BODY MOUNT ARM PIN
 H0473 FRONT BODY MOUNT PLATE CFRP
 H0475 CHASSIS
 D0506 REAR DAMPER SHAFT



D0508 DIAPHRAGM
 D0509 O-RING SET
 H0510 DAMPER PISTON
 H0511 FRONT DAMPER SPRING BLACK ϕ 1.9mm
 H0513 SPRING ADJUSTER
 H0515 FRONT DAMPER SPRING YELLOW ϕ 1.8mm
 H0516 FRONT DAMPER SPRING BLUE ϕ 2.0mm
 H0525 FRONT DAMPER SPRING GRAY ϕ 1.8mm
 H0526 FRONT DAMPER SPRING WHITE ϕ 1.9mm
 H0529 REAR DAMPER SPRING GRAY ϕ 1.8mm
 H0530 REAR DAMPER SPRING WHITE ϕ 1.9mm
 H0531 REAR DAMPER SPRING PINK ϕ 2.0mm
 H0532 REAR DAMPER SPRING RED ϕ 2.0mm
 H0554 DAMPER CAP
 H0558 DAMPER PISTON (ϕ 1.2)
 H0559 DAMPER PISTON (ϕ 1.3)
 H0560 FRONT DAMPER STAY
 H0561 REAR DAMPER STAY
 H0562 DAMPER CASE
 H0563 OIL SEAL CAP
 H0566 FRONT DAMPER STAY
 H0570 DAMPER SET
 H0571 DAMPER PARTS

